



ISP and I.ISP Crestron Module




« *Advanced* » *Template description*

Standard preset



Adjustment Panel selection



1. Power Status

Main Theater


2. Volume
3. Audio adjustments
4. Listening preset
5. Audio Source selection
6. Audio stream information
7. Preferred Upmix selection
8. Upmix settings (allowed ones)

Audio Zones

9. Audio Zones selection and adjustments

In the current state, Source selection is identical for Main Theater and Audio Zone

Standard preset



Zone Audio Adjustments

For each Audio Zone defined, a dedicated area includes all related and allowed adjustments.

SphereAudio preset



1. Preset selected is now the one activating SphereAudio mode
Main Theater gets disabled, together with all related adjustments.
2. A new Setting SphereAudio Effect becomes available
This Setting is common to all Headphones zones activated
3. Audio zone selection
Will show available activated headphones zones
4. SphereAudio status
Each Headphones can individually enable or disable the SphereAudio effect



1. Product information

2. Connection status

Connect/disconnect the unit to network

3. Power

Turn unit to On / Sleep Modes

4. Restart

Will force the unit to reboot.

5. Triggers

Show triggers status and when adjustable, allow for change

Inputs page

GeneralInputsZonesSettings

OnOff

StormAudio Connection: 13/06/2017 11:46

Scroll vertically to see the full list

<u>HDMI 1</u> Audio type: HDMI1 Video type: HDMI1	<u>HDMI 2</u> Audio type: HDMI2 Video type: HDMI2	<u>HDMI 3</u> Audio type: HDMI3 Video type: HDMI3	<u>HDMI 4</u> Audio type: HDMI4 Video type: HDMI4
<u>HDMI 5</u> Audio type: HDMI5 Video type: HDMI5	<u>HDMI 6</u> Audio type: HDMI6 Video type: HDMI6	<u>HDMI 7</u> Audio type: HDMI7 Video type: HDMI7	<u>HDMI 8</u> Audio type: HDMI8 Video type: HDMI8
<u>Optical 1</u> Audio type: HDMI1 Video type: OPTICAL1	<u>Optical 2</u> Audio type: HDMI1 Video type: OPTICAL2	<u>Optical 3</u> Audio type: HDMI1 Video type: OPTICAL3	<u>Coaxial 1</u> Audio type: HDMI1 Video type: COAX1

The Inputs page show you the definition of all the available and activated sources as defined in ISP / I.ISP Web User Interface.

